



Phone (410) 820-5111
Toll Free(800) 626-7713
Fax (410) 822-9633

Ohmic Instruments
3081 Elm Point Industrial Drive
St. Charles, MO 63301 USA

www.ohmicinstruments.com
Sales: sales@ohmicinstruments.com
Service: service@ohmicinstruments.com

USING THE DPA-10 WITH THE EM-3

To use the DPA-10 Dewpoint adapter requires an EM-3 Environmental Monitor and a Computer. Connect the green split connector on the DPA-10 to the split connector on the EM-3 (EM-3 should be connected and installed as per its instructions). Connect the inlet port to sample air. If sample is over 5 PSI connect the brass orifice assembly. If not the outlet can be exhausted to ambient.

*Both the EM-3 and DPA-10 are powered by the computers USB port. If you computer has many USB devices active the voltage may become to low to operate properly.

